

# Installing the nozzles, you can make the system virtually invisible



**when we move in... they move out.**



**MosquitoMax™**  
misting systems

# Nozzle Positioning- Eave examples



With vinyl siding you can neatly tuck the tubing behind the siding or underneath the fascia cover lip



**when we move in... they move out.**



# Installing your on Eaves nozzles

- **Eaves:** When running the tubing lines on eaves, we usually recommend running the lines in the crease behind the fascia at the soffit edge. Usually enough blow back occurs to keep spiders and wasps from nesting. If you have a very deep covered patio, you might need to run additional nozzles that spray from the house to get the necessary coverage. Make sure you install union tees at the points where you want to come off the house to your fence or yard (downspouts and corners) are inconspicuous places. Continue your eave runs to keep your lines straight, once your eave runs are finished, then connect the lines coming from your yard up from the base of your downspout and make the connection at the union tee. Use plastic tie wraps to fasten and hide the line to the back or side of the downspout to finish up.

# Eave installation examples



**when we move in... they move out.**